



Inverter/Battery Configuration Guide

Battery/Inverter	H1/AC1 (Min.- Max.)	KH/KA (Min.-Max.)	H3/AC3 (Min.-Max.)	H3 PRO* (Min.-Max.)	AIO-H1 (Min.-Max.)	AIO-H3 (Min.- Max.)
HV2600	2 – 7	2 – 8	4 – 8	4 – 9	2 – 4	4
Mira-HV25	2 – 7	2 – 8	4 – 8	4 – 9	N/A	N/A
CM2800&CS2800	(1M.+1S.) - (1M.+6S.)	(1M.+1S.) - (1M.+6S.)	(1M.+2S.) - (1M.+6S.)	(1M.+3S.) - (1M.+8S.)	N/A	N/A
CM2900&CS2900	(1M.+1S.) - (1M.+6S.)	(1M.+1S.) - (1M.+6S.)	(1M.+2S.) - (1M.+6S.)	(1M.+3S.) - (1M.+8S.)	N/A	N/A
CM4100&CS4100	(1M.+1S.) - (1M.+6S.)	(1M.+1S.) - (1M.+6S.)	(1M.+2S.) - (1M.+6S.)	(1M.+3S.) - (1M.+8S.)	N/A	N/A
CM4300&CS4300	(1M.+1S.) - (1M.+6S.)	(1M.+1S.) - (1M.+6S.)	(1M.+2S.) - (1M.+6S.)	(1M.+3S.) - (1M.+8S.)	N/A	N/A
CM4800&CS4800	(1M.+1S.) - (1M.+6S.)	(1M.+1S.) - (1M.+6S.)	(1M.+2S.) - (1M.+6S.)	(1M.+3S.) - (1M.+8S.)	N/A	N/A

*H3 Pro >25kW has two battery inputs therefore the stated battery numbers can be doubled.